


## Springtester – Max Spring length

### I. Compression Tests

#### Description of parts and functions

#### Dimension:



9. „Compress slaver“ stand for the maximum distance of the upper and lower compression plates.

This maximum distance is exactly 100 mm.

This distance is the “room” in which a test spring can be inserted.

### II. Tension Tests

The minimum distance between the upper and lower hook is 64 mm.