

IP protected bench scale KERN FXN







Robust, space-saving bench scale, protected by stainless steel and IP68 rating – also with EC type approval [M]

Features

- Suitable for the ever-increasing hygienic requirements in the food industry
- · Your support in a HACCP-compliant quality system
- · Ideal for the robust industrial applications
- · Very high class of protection against dust and water IP68, ideal for harsh ambient conditions. Submersion in water actually possible
- · Particularly suitable to determine the specific weight of organs, tissues, etc. in Pathology or in the laboratory
- · Stainless steel design of the housing and weighing plate. Its smooth surfaces make it simple to clean
- · Very fast display: steady weight values
- · High mobility: thanks to battery operation, compact, lightweight construction, it is suitable for the use in several locations
- 11 Recessed grips on the underside of the scale for easy transportation

• Weighing with tolerance range (checkweighing): a visual and audible signal helps with portioning, dispensing or grading

Technical data

- · Large backlit LCD display, (FXN-M: green) digit height 25 mm
- Dimensions weighing surface, stainless steel, W×D 236×195 mm
- Overall dimensions W×D×H 240×280×120 mm
- Ready for use: Batteries included, 4×1.5 V Size D, Operating time without backlight FXN-N up to 200 h, FXN-M 500 h, AUTO-OFF function to preserve the battery
- · Net weight 3,2 kg
- Permissible ambient temperature -10 °C/40 °C

Accessories

· Tare pan made from stainless steel. Ideal for weighing loose small parts, fruit, vegetables, etc. W×D×H 370×240×20 mm, KERN RFS-A02

Note: Official verification duty for commercial trade

965-228

965-228

963-128

963-128

STANDARD





FXN 10K-3M

FXN 30K-2M













15





5

10





		·								
Model	Weighing	Readability	Verification	Minimal load	Smallest part		Option			
	capacity		value		weight		Verification		DAkkS Calibr. Certificate	
	[Max]	[d]	[e]	[Min]	[Normal]		MIII		DAkkS	
KERN	kg	g	g	g	g/piece		KERN		KERN	
FXN 3K-4N	3	0,5	-	_	5		-		963-127	
FXN 6K-3N	6	1	-	_	10		-		963-128	
FXN 10K-3N	15	2	-	-	20		-		963-128	
FXN 30K-3N	30	5	-	_	50		-		963-128	
Note: For applications that require verification, please order verification at the same time, initial verification at a later date is not possible.										

Verification at the factory, we need to know the full address of the location of use. FXN 3K-3M 3 965-227 963-127 965-228 FXN 6K-3M 2 40 10 963-128 6

20

100

200

5

KERN BALANCES & TEST SERVICES CATALOGUE 2021



Pictograms



Internal adjusting:

Quick setting up of the balance's accuracy with internal adjusting weight (motordriven)



Adjusting program CAL:

For quick setting up of the balance's accuracy. External adjusting weight required



Easy Touch:

Suitable for the connection, data transmission and control through PC, tablet or smartphone.



Memory:

Balance memory capacity, e.g. for article data, weighing data, tare weights, PLU etc.



Alibi memory:

Secure, electronic archiving of weighing results, complying with the 2014/31/EU standard



Data interface RS-232:

To connect the balance to a printer, PC or network



RS-485 data interface:

To connect the balance to a printer, PC or other peripherals. Suitable for data transfer over large distances. Network in bus topology is possible



USB data interface:

To connect the balance to a printer, PC or other peripherals



Bluetooth* data interface:

To transfer data from the balance to a printer, PC or other peripherals



WiFi data interface:

To transfer data from the balance to a printer, PC or other peripherals



Control outputs (optocoupler, digital I/O):

To connect relays, signal lamps, valves, etc.



Analogue interface:

to connect a suitable peripheral device for analogue processing of the measurements



Interface for second balance:

For direct connection of a second balance



Network interface:

For connecting the scale to an Ethernet network



KERN Communication Protocol (KCP):

It is a standardized interface command set for KERN balances and other instruments, which allows retrieving and controlling all relevant parameters and functions of the device. KERN devices featuring KCP are thus easily integrated with computers, industrial controllers and other digital systems



GLP/ISO log:

The balance displays serial number, user ID, weight, date and time, regardless of a printer connection



GLP/ISO log: With weight, date and time. Only with KERN printers



Piece counting:

Reference quantities selectable. Display can be switched from piece to weight



Recipe level A:

The weights of the recipe ingredients can be added together and the total weight of the recipe can be printed out



Recipe level B:

Internal memory for complete recipes with name and target value of the recipe ingredients. User guidance through display



Totalising level A:

The weights of similar items can be added together and the total can be printed out



Percentage determination:

Determining the deviation in % from the target value (100 %)



Weighing units:

Can be switched to e.g. nonmetric units at the touch of a key. See balance model. Please refer to KERN's website for more details



Weighing with tolerance range:

(Checkweighing) Upper and lower limiting can be programmed individually, e.g. for sorting and dosing. The process is supported by an audible or visual signal, see the relevant model



Hold function:

(Animal weighing program) When the weighing conditions are unstable, a stable weight is calculated as an average value



Protection against dust and water splashes IPxx:

The type of protection is shown in the pictogram



Suspended weighing:

Load support with hook on the underside of the balance



Battery operation:

Ready for battery operation. The battery type is specified for each device



Rechargeable battery pack:

Rechargeable set



Universal mains adapter:

with universal input and optional input socket adapters for A) EU, CH, GB; B) EU, CH, GB, USA; C) EU, CH, GB, USA, AUS



Mains adapter:

230V/50Hz in standard version for EU, CH. On request GB, USA or AUS version available



Power supply:

Integrated in balance. 230V/50Hz standard EU. More standards e.g. GB, USA or AUS on request



Weighing principle: Strain gauges:

Electrical resistor on an elastic deforming body



Weighing principle: Tuning fork:

A resonating body is electromagnetically excited, causing it to oscillate



Weighing principle: Electromagnetic force compensation:

Coil inside a permanent magnet. For the most accurate weighings



$\label{thm:continuous} \mbox{Weighing principle: Single cell technology:}$

Advanced version of the force compensation principle with the highest level of precision



Verification possible:

The time required for verification is specified in the pictogram



DAkkS calibration possible (DKD):

The time required for DAkkS calibration is shown in days in the pictogram



Factory calibration (ISO):

The time required for Factory calibration is shown in days in the pictogram



Package shipment:

The time required for internal shipping preparations is shown in days in the pictogram



Pallet shipment:

The time required for internal shipping preparations is shown in days in the pictogram

KERN - Precision is our business

To ensure the high precision of your balance KERN offers you the the appropriate test weight in the international OIML error limit classes E1-M3 from 1 mg - 2500 kg. In combination with a DAkkS calibration certificate the best pre-requisite for proper

The KERN DAkkS calibration laboratory today is one of the most modern and best-equipped DAkkS calibration laboratories for balances, test weights and force-measure-

Thanks to the high level of automation, we can carry out DAkkS calibration of balances, test weights and force-measuring devices 24 hours a day, 7 days a week.

. . .

- DAkkS calibration of balances with a maximum load of up to 50 t
- DAkkS calibration of weights in the range of 1 mg 2500 kg
- Volume determination and measuring of magnetic susceptibility (magnetic characteristics) for test weights
- Database supported management of checking equipment and reminder service
 Calibration of force-measuring devices
- DAkkS calibration certificates in the following languages DE, EN, FR, IT, ES, NL, PL
 Conformity evaluation and reverification of balances and test weights

Your KERN specialist dealer:

^{*}The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by KERN & SOHN GmbH is under license. Other trademarks and trade names are those of their respective owners.