

TOILET PAPER DISPENSER MEDICLINICS ®

Surface mounted, three standard rolls steel white epoxy

General description

- · Toilet paper dispenser for three standard rolls, surface mounted, steel white epoxy coated.
- · Manual dispensing.
- · Suitable for high traffic facilities.
- · Model suitable for public use.
- \cdot It generally goes along with a toilet brush holder and toilet paper waste receptacle, steel white epoxy

Components and Materials

- \cdot Steel white epoxy coated one-piece body, 0,8 mm thick, fully sealed. The supports of the screws in the back of the appliance, are acting as an anti-moisture support, as well as slots to avoid the screws damaging the toilet paper. It is mounted on the wall by means of 3 wood screws with their corresponding 5 mm wall plugs. It includes a lock system with standard mediclinics ® key, that allows opening the lid for replenishment.
- · Steel white epoxy coated one-piece seamless lid, 0,8 mm thick, fully sealed. Fixed to the body by means of 2 rivets that allows swinging of the lid for the replenishment through the top opening. The extra tissue rolls descend when the previous one has been finished, by a simple hand manipulation through the side window. There is no need to open the lid for the removal of consumed rolls.
- · Frontal sight-hole and slots on each side of body indicate refill time.

Technical Specifications

Dimensions - 380x 116x 130 mm

Weight (empty dispenser) - 1,3 Kg

Toilet paper roll diameter - Ø 105-125 mm (maximum)

Size toilet paper roll - 110 mm (maximum)

Recommended installation height to the bottom - 65-75 cm

116 mm (4-9/16") 380 mm (5-1/8") 130 mm (15") 130 mm (15") 130 mm (5-1/8") Dim.: ±4%

Código: PR0781

Operation

Certificates & Qualifications

ISO 9001:2008.

Mediclinics, S.A., reserves the right to make changes and/or modifications to the products and their specifications without prior notice.



mediclinics S.A